

HYPERION FLOOD LIGHTS | MOUNTING ACCESSORIES



MOUNTING ARM




STAKE

ACCESSORY	CODE
MOUNTING ARM 500MM BLACK	BL-CS-ARM500B
MOUNTING ARM 800MM BLACK	BL-CS-ARM800B
MOUNTING ARM 1000MM BLACK	BL-CS-ARM1000B
STAKE 250MM BLACK	BL-CS-STAKE250B

MOUNTING ARM INSTRUCTIONS

1. Fasten the bracket onto flood light with screws provided. Adjust the flood light to direct the light in the desired direction before tightening the screws.
2. Attach flood light bracket to the mounting arm with bolts.
3. Thread power cable through end plug and then through arm.
4. Fasten arm to wall with 4 screws appropriate to situation.



MOUNTING STAKE INSTRUCTIONS

1. Fasten the bracket onto flood light with screws provided. Adjust the flood light to direct the light in the desired direction before tightening the screws.
2. Secure stake in ground. *(This can be done before or after attaching flood light).*
3. Attach flood light to mounting stake with bolt through central bracket hole.

